OPERATION
SAFETY
SERVICE
WARRANTY
CONTACT
SPECIFICATIONS
TROUBLESHOOTING

Grizzly GP-33

Instruction Manual

Intertek

B-AiR

THANK YOU FOR PURCHASING A B-AIR PRODUCT.

Introduction to Grizzly GP-33

Your new Grizzly B-Air #GP-33 dryer / air mover has a 1/3 hp high efficiency motor with the following features:

- State of the art construction
- Stackable
- 25 foot cord
- Low amps (l 2.8a/ m2.85a / h3.65a)
- 2700 cfm
- “daisy chain capability” up to 3 units
- Built in gfci breaker
- Safety screens on open vents
- Easy grip carrying handle
- Swing out kick- stand.
- Safety locks to lock adapter (#ddk)
- Safety green
- 3 speed switch

Operation/Use

This high air volume dryer / air mover is intended to dry floors, carpets, walls, etc. And circulate air.

A) Carefully place the Grizzly B-Air unit on a stable flat dry surface during oper ation.
B) Use free standing or with attachments
The Grizzly B-Air unit can be positioned to aim airflow across flat surfaces or angled upward. Raise or lower the attached kick stand for height adjust ment.
C) Turn on the switch to desired speed and make sure it is operating correctly.
D) All dryers / air movers in operation must be supervised at all times.

Storage

Store unit indoors in a clean dry environment to ensure long life

Safety

1) Keep children and pets away from unit while in operation and/or plugged in.
2) Do not put fingers or other objects in unit while in operation and/or plugged in.
3) To avoid electric shock do not operate in pooled water.
4) Unit must be kept dry at all times, including motor, wiring and exterior. If unit becomes wet, thoroughly dry before next operation.
5) Indoor use: use only with a grounded plug and/or extension cord to avoid risk of electrical shock or fire. Remember never to use a cord with any kind of damage or wear.
6) Make sure the power source is sufficient to meet the requirements of the dryer / air mover.
7) To prevent overheating the unit, keep air intakes clear at all times.
8) Clogging or blocking the air intakes could result in a fire or electrical hazard.
9) In order to prevent injury do not remove any screens or safety guards from the unit and to avoid objects from coming in contact with the dryer's wheel. Unit damage in this manner will void your warranty.
10) Do not operate unit close to any dangerous areas, such as explosive gases, flammables, heaters and unventilated environments, which may result in explosions or electrical hazards.
11) Do not use any form of speed control device as doing so may cause injury or fire.
12) Always place dryer / air mover on a smooth and leveled surface for safe opera tion.
13) Do not use unit if damaged.
14) Before cleaning or servicing unplug unit.
15) All dryers / air movers in operation must be supervised at all times.
16) Do not expose to rain, water or snow.
17) Unit must be connected to a GFCI (ground fault circuit interrupter) protected receptacle.

Warning!

All dryers / air movers in operation must be supervised and attended at all times. The use of a 3-prong to 2-prong adapter is prohibited. Only use a 2-prong to 2-prong adapter.

If the power supply cord is damaged, it must be replaced by the manufacturer, its service agent or similarly qualified persons in order to avoid a hazard.

Limited Warranty

Proof of purchase is required on all warranty claims.

1 Year Warranty:

B-air will cover all parts (except power cord) within one year of purchase b-air will pay repair costs and one way ups ground service shipping to your location within the 48 contiguous states. Proof of purchase is required.

Customer is responsible for shipment of damaged unit to b-air warehouse for repair. Canada and non-contiguous states must pay freight both ways.

5 Year Warranty:

B-air will cover housing from date of original purchase. Proof of purchase is required.

Grizzly B-Air Limited Warranty

Covers

1) Grizzly B-Air dryers / air movers are covered against defects in material and craftsmanship used under normal intended use to original purchaser for a term of (1) one-year from the original date of purchase including parts, labor and shipping.
2) Grizzly b-air dryer / air mover's housing is covered for a term of (5) five full years from the date of the original purchase.

Does not cover

Any signs of misuse including, but not limited to rough handling, abuse, tampering, improper voltage use, and unauthorized maintenance and repairs.

Service

In order to receive service or replacement parts under warranty, you must:

1) Call for a RMA# (return merchandise authorization number)
2) Have proof of purchase
3) Ship to B-Air blower

• If immediate service is required, b-air will ship a refurbished dryer / air mover immediately to replace the one requiring service provided a valid credit card is provided and charged. once we receive your dryer / air mover, we will credit your credit card account.
• We will gladly repair your dryer / air mover and ship within 24 hours.

Upon inspection, we will advise you of the repairs needed and the cost (if applicable).
B-Air will issue repair or replacement parts depending on warranty.

Cords

1) Do not use extension cords for outside use.
2) Use 3 prong adaptors that are UL and CE approved and not less than 14-3 with ground fault circuit interrupter (GFCI).
3) Do not use cords that show any kind or wear or damage.
4) Cords are not covered by warranty.

Grizzly GP-33
PART LIST

A. Housing		X1
B. Motor		X1
C. Fan		X1
D. Air Exhaust Grill		X1
E. Air Intake Grill (M)		X1
F. Air Intake Grill (F)		X1
G. Power Cord		X1
H. GFCI		X1
I. GFCI Cover		X1
J. Air Guide Blade		X1
K. Capacitor		X1
L. Fastener Clip		X2
M. Switch		X1
N. Switch Knob		X1
O. Switch Cover		X1
P. Rivet 4x16mm		X13
Q.Rivet 5x19mm		X14
R. Screw 3x10mm		X4
S. Screw 4x16mm		X10
T. Screw 4x12mm		X4
U. Screw 6x16mm		X4
V. Rack Feet		X2
W. Rack Tube		X2
X. Cord Connector		X1
Y. Kick Stand		X1
Z1. Rubber Feet		X2
Z2. Rubber Feet		X4

Explosion of Grizzly GP-33



Troubleshooting

PROBLEM	POSSIBLE CAUSE	SOLUTION
Motor Not Running	a) Switch is OFF	a) Turn Switch ON
	b) Bad Outlet	b) Check Outlet/ Change to Another Outlet
	c) Faulty Switch/Cord	c) Call Factory for new Switch/Replace Cord
Scraping Noise From Blower	a) Wheel Out Of Line	a) Call Factory for Replacement Advise
Weak Air Flow	a) Obstructed Vents/Inlets	a) Clean Out Vents/Inlets

Specifications

VOLTS	115 V
CYCLE	60 Hz
MAX AIR VOLUME	2700 CFM
AMPS	L2.8/ M2.85 / H3.65
MAX STATIC PRESSURE	1.4"
WEIGHT NET/SHIP	28/32 LBS
UNIT SIZE (L x W x H)	19" x 18" x 17.5"
WHEEL SPEED (RPM)	L990 / M1070 / H1140
MOTOR	1/3 HP
ATTACHED CORD (14G)	25 FT /14G
SPEEDS	3
KICK STAND HEIGHT	4.5"

WARRANTY REGISTERATION

Please complete and mail or fax for your product warranty, for a multiple units, please list serial numbers on a separate sheet

THIS WARRANTY CARD AND YOUR BILL OF SALE MUST BE PRESENTED FOR WARRANTY SERVICE.

Your Company Name _____

Contact Name _____ Title _____

Address _____

City _____ State _____ Zip _____

Phone _____ Fax _____

E-mail _____

GRIZZLY GP-33

Serial Number _____ **Date of Purchase** _____/_____/_____

Purchased From _____

Additional Comments/Suggestions _____

_____

_____

Intertex, Inc. / B-Air Blowers

1851 Tyburn Street, Glendale, CA 91204

1-877-800-2247 (BAIR)

Fax: (818) 242-2430

Email: info@b-air.com

Web site: www.b-air.com

PLACE
STAMP
HERE

Intertex, Inc. / B-Air Blowers
1851 Tyburn Street, Glendale, CA 91204